

| <b>CHRT specification</b> |  |
|---------------------------|--|
| case                      | 2U 19" rack  |
| dimensions                | width = 482.6 mm (436 mm without rack ears)                                    |
|                           | height = 88.2 mm   |
|                           | depth = 100 mm   |
| weight                    | 1.5 kg   |
| power                     | 230V / 50Hz / 17 W IEC 60320 C14   |
| fuses                     | PRIMARY: T 0.125A in the AC power outlet                                       |
|                           | SECONDARY 1: T 0.125A rear panel   |
|                           | SECONDARY 2: T 0.315A rear panel   |
| valves                    | 21TE31 (2D21)  |
|                           | 2x ECC81   |
|                           | EF86   |
| inputs                    | MIDI IN (DIN 5 female)   |
|                           | WX IN (MINI DIN 5 male) for Yamaha WX5 direct connection including 9V DC power |
| outputs                   | MONO OUT (TRS 6.35 mm female) balanced or unbalanced                           |
|                           | MIDI THRU (DIN 5 female)   |
| <b>CONTROLS</b>           |  |
| oscillator                | TRIGGER PULSE AMPLITUDE  |
|                           | TRIGGER BIAS   |
|                           | DRIVE  |
|                           | VOLTAGE  |
|                           | LOAD   |
| resonator                 | OSCILLATOR SELECT  |
|                           | FILTER STAGE INPUT GAIN  |
| VCA                       | VCA DRIVE  |
|                           | VOLUME   |
| MIDI                      | MIDI IN SELECT rear panel  |
|                           | MIDI PANIC   |
| power and ground          | POWER ON/OFF   |
|                           | HUM DINGER   |
|                           | GROUND LIFT rear panel   |